


 PIONEER®

# Service Manual

## REPAIR & ADJUSTMENTS



ORDER NO.  
ARP-293-0

AM/FM STEREO RECEIVER

# SX-60

MODEL SX-60 COMES IN FOUR VERSIONS DISTINGUISHED AS FOLLOWS:

Type	Voltage	Remarks
KU	AC120V only	U. S. A. model
KC	AC120V only	Canada model
S	AC110V, 120V, 220V, 240V (switchable)	General export model
S/G	AC110V, 120V, 220V, 240V (switchable)	U. S. Military model

- This service manual is applicable to the KU type.  
For servicing of the other types, please refer to the additional service manual.
- For the circuit descriptions, please refer to the SX-60, SX-50, SX-40 service manual (ARP-393-0).
- Ce manuel d'instruction se réfère au mode de réglage, en français.
- Este manual de servicio trata del método de ajuste escrito en español.

## CONTENTS

1. SPECIFICATIONS .....	2	7. ELECTRICAL PARTS LIST .....	24
2. FRONT PANEL FACILITIES .....	3	8. PACKING .....	27
3. PARTS LOCATION .....	5	9. ADJUSTMENT .....	28
4. EXPLODED VIEW AND PARTS LIST .....	7	RÉGLAGE .....	30
5. SCHEMATIC DIAGRAM .....	11	AJUSTE .....	32
6. P. C. BOARDS CONNECTION DIAGRAM ....	17	10. SAFETY INFORMATION .....	34

# 1. SPECIFICATIONS

## Amplifier Section

Continuous Average Power Output is 80 watts\* per channel, min., at 8 ohms from 20 Hertz to 20,000 Hertz with no more than 0.005% total harmonic distortion.\*\*

Intermodulation Distortion (50 Hertz; 7,000 Hertz = 4:1, 8 ohms, from POWER IN)	
continuous rated power output . . . . .	No more than 0.005%
Input (Sensitivity/Impedance)	
PHONO MM . . . . .	2.5mV/50kilohms
PHONO MC . . . . .	0.25mV/100ohms
CD/AUX, TAPE PLAY1, 2, VIDEO . . . . .	150mV/50kilohms
Phono Overload Level (T.H.D. 0.007% 1,000Hz)	
PHONO MM . . . . .	150mV
PHONO MC . . . . .	.14mV
Output (Level/Impedance)	
TAPE REC 1, 2 . . . . .	150mV/2.2kilohms
SPEAKER . . . . .	A, B, A series B, off (6 to 16ohms)
Frequency Response	
PHONO (RIAA Equalization) . . . . .	20Hz to 20,000Hz ± 0.3dB
CD/AUX, TAPE PLAY 1, 2, VIDEO . . . . .	5Hz to 100,000Hz +0 -3dB
Tone control	
BASS . . . . .	±8dB (100Hz)
TREBLE . . . . .	±8dB (10kHz)
Loudness Contour (Volume control set at -40dB position)	
. . . . .	+6dB (100Hz), +3dB (10,000Hz)
Filter	
SUBSONIC . . . . .	20Hz (6dB/oct)
Hum and Noise (IHF, short circuited, A network)	
PHONO MM . . . . .	86dB
PHONO MC . . . . .	67dB
CD/AUX, TAPE PLAY1, 2, VIDEO . . . . .	95dB

## FM Tuner Section

Frequency range . . . . .	87.5MHz to 108MHz
Usable Sensitivity . . . . .	10.3 dBf, IHF (0.9μV/75ohms)
50dB Quieting Sensitivity	
MONO . . . . .	15.7dBf, IHF (1.6μV/75ohms)
STEREO . . . . .	37dBf, IHF (19.5μV/75ohms)
Signal-to-Noise Ratio	
MONO . . . . .	83dB (at 65dBf)
STEREO . . . . .	80dB (at 85dBf)

## Distortion (at 65dBf)

MONO 100Hz . . . . .	0.1%
1kHz . . . . .	0.07%
6kHz . . . . .	0.15%
STEREO 100Hz . . . . .	0.2%
1kHz . . . . .	0.1%
6kHz . . . . .	0.25%

Capture Ratio . . . . . 1.0dB

Alternate Channel Selectivity . . . . . 400kHz; 80dB

Stereo Separation . . . . . 1kHz; 50dB

30Hz to 15kHz; 35dB

Frequency Response . . . . . 20Hz to 15kHz +0 -1.0 dB

AUTO TUNING threshold . . . . . 29.3dBf (8μV/75ohms)

Antenna Input . . . . . 300ohms balanced, 75 ohms unbalanced

## AM Tuner Section

Frequency range . . . . .	522kHz to 1620kHz
(When 10kHz step)	520kHz to 1620kHz
Sensitivity (IHF, Loop antenna) . . . . .	220μV/m
(IHF, EXT. antenna) . . . . .	10μV
Selectivity . . . . .	60dB
Signal-to-Noise Ratio . . . . .	50dB
Antenna . . . . .	High sensitivity Loop Antenna

## Miscellaneous

Power Requirements . . . . .	AC 120V, 60Hz
Power Consumption . . . . .	310W (UL)
Dimensions . . . . .	420(W) x 130(H) x 364(D) mm
	16-9/16(W) x 5-2/16(H) x 14-5/16(D) in
Weight (without package) . . . . .	10.3kg (22lb 11oz)

## Furnished Parts

FM T-type Antenna . . . . .	1
AM Loop Antenna . . . . .	1
Operating Instructions . . . . .	1


\* Measured pursuant to the Federal Trade Commission's Trade Regulation rule on Power Output Claims for Amplifier.

\*\* Measured by Audio Spectrum Analyzer.

## NOTE:

Specifications and the design subject to possible modifications without notice due to improvements.

## 2. FRONT PANEL FACILITIES



### ① POWER SWITCH

Power is supplied to the unit when this switch is depressed. To turn off the power, release the switch.

### ② PHONES JACK

Plug the headphones into this jack when you want to listen to a performance alone.

- When listening through the headphones alone, set both SPEAKERS SWITCHES A and B to OFF.

### ③ TONE CONTROL

This control is used to adjust the tone quality.

**BASS** . . . Use this control to adjust the bass of the sound. When the control is moved from the central position towards "MIN", the bass is attenuated and when it is moved towards "MAX", the bass is emphasized.

**TREBLE** . . Use this control to adjust the treble of the sound.

When the control is moved from the central position towards "MIN", the treble is attenuated and when it is moved towards "MAX", the treble is emphasized.

### ④ TAPE MONITOR SWITCHES

Use these switches when playing back tapes or monitoring a recording. There are tape terminals for two systems on this receiver. Two tape decks can be attached and record-

ing or playback performed. The two tape decks can also be used for recording simultaneously or for copying from one tape to another (but only from tape deck 1 to tape deck 2).

**TAPE 1** . . Press when performing with a tape deck connected to the TAPE 1 jacks on the rear panel. Also, press when copying a tape from tape deck 1 to tape deck 2.

**TAPE 2** . . Press when performing with a tape deck or other adaptor connected to the TAPE 2 jacks on the rear panel.

### ⑤ FUNCTION SWITCHES

#### VIDEO SWITCH:

Press this switch when listening to a video unit such as a VCR or laser disc player connected to the VIDEO SOUND jacks on the rear panel.

#### CD/AUX SWITCH:

Press this switch when listening to a compact disc player (CD player) or TV tuner connected to the CD/AUX jacks on the rear panel.

#### AM SWITCH:

Press this switch for AM reception.

#### FM SWITCH:

Press this switch for FM reception.

#### PHONO SWITCH:

Press this switch when listening to a record on a turntable connected to the PHONO jacks on the rear panel.

### ⑥ TUNING MODE SWITCH

This switch is used to select either AUTO search or MANUAL tuning.

#### AUTO (released position):

When the TUNING switch is pressed, the broadcasting stations are automatically scanned. Once a station has been found, the scanner stops at that frequency. To listen to another station, press the TUNING switch once again and the procedure is repeated. The procedure stops as soon as another station is found.

#### MANUAL (depressed position):

For normal manual tuning.

Press the TUNING switch and tune in to the desired station manually.

#### NOTES:

- If the broadcasting station is distant and its signals weak, you may not be able to find the station with AUTO tuning. In such an event, tune in to the desired station using MANUAL mode (■ depressed position).

- If the AUTO mode stops frequently when trying to tune into an AM broadcast because of city interference or weak nighttime stations, tune in using the MANUAL mode (■ depressed position).

### ⑦ TUNING SWITCHES

These are used to select the broadcasting station.

During MANUAL tuning, if the TUNING switch is depressed once, the frequency changes one step at a time. If the TUNING switch is kept depressed, the frequency changes continuously.

#### NOTE:

During AUTO SEARCH tuning, intermittent noise may occur, but this is not a malfunction.

### ⑧ MEMORY SWITCH

This switch is used to preset the broadcasting stations into the STATION CALL switches.

When this switch is depressed, the STATION indicators light up from 1 to 10 in sequence. To preset the station, press the STATION CALL switch when the indicator lights up.

### ⑨ MONO SWITCH

This switch is depressed to mix the L and R channel stereo input signals and listen to them in mono through both the left and right speakers.

### ⑩ LOUDNESS SWITCH

When listening to a performance when the VOLUME level is low, depress this switch and the bass and treble will be accentuated.

When the volume is low, the human ear finds it harder to hear the bass and treble than when the volume is high. The LOUDNESS switch is thus designed to compensate for this deficiency.

### ⑪ VOLUME/BALANCE CONTROL

The inside knob is the VOLUME control and the outside knob the BALANCE control.

### VOLUME:

This control is used to adjust the volume of the speakers and headphones. To increase the output level, turn the knob slowly clockwise (↗).

### BALANCE:

This control is used to balance the volume of the left and right channels. If the sound appears to be weaker from the right speaker, turn the BALANCE control clockwise (↗). If the sound is weaker from the left speaker, turn the control counterclockwise (↖).

#### NOTE:

When operating the VOLUME control, be careful not to turn the BALANCE control at the same time.

### ⑫ STATION CALL SWITCHES

Once the broadcasting stations are preset to these STATION CALL switches, the desired station can be received merely by pressing the appropriate switch and without having to operate the TUNING switch each time.

### ⑬ PHONO SELECTOR SWITCH

When playing a record on a turntable, adjust this switch in accordance with the cartridge type being used.

Depress the switch (■ MC) when listening to a performance from an MC cartridge turntable. Release the switch (■ MM) when using an MM cartridge turntable.

### ⑭ SUBSONIC SWITCH

When this switch is depressed, the subsonic filter operates. The filter attenuates frequencies lower than 20Hz by 6dB/oct and can be used to suppress the ultra low range noise generated by record warp and other factors. This noise cannot actually be heard by the ear, but it can cause intermodulation distortion and even damage to the speaker systems. Use therefore as required.

### ⑮ SIMULATED STEREO SWITCH

This turns monaural signals into simulated stereo sound. Use this when you wish to experience the sense of stereo presence with AM broadcasts, VCR or other monaural signal sources.

#### NOTE:

This function can also be used with stereo sources, but it will result in a different sound from the normal stereo sound.

### ⑯ SPEAKERS SWITCHES

Depress the switch corresponding to the speakers connected to the SPEAKERS terminals (A and B) on the rear panel. "A" refers to the speakers which have been connected to the A SPEAKERS terminals, while "B" refers to the speakers which have been connected to the B SPEAKERS terminals.

#### NOTE:


No sound will be heard through the speakers when both A and B switches are depressed if only one set of speakers has been connected to either A or B SPEAKERS terminals.

### 3. PARTS LOCATION


**NOTES:**

- The **▲** mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- For your Parts Stock Control, the fast moving items are indicated with the marks **★★** and **★**.  
**★★ GENERALLY MOVES FASTER THAN ★**  
 This classification shall be adjusted by each distributor because it depends on model number, temperature, humidity, etc.


#### Front Panel View




#### Front View



#### Top View



#### Rear View




#### **4. EXPLODED VIEW AND PARTS LIST**

### *NOTES:*

- *Parts without part number cannot be supplied.*
  - *The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.*
  - *For your Parts Stock Control, the fast moving items are indicated with the marks ★★ and ★*  
**★★ GENERALLY MOVES FASTER THAN ★**  
*This classification shall be adjusted by each distributor because it depends on model number, temperature, humidity, etc.*

## **Exterior Components**



## Parts List

<u>Mark</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Mark</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1.	BBZ30P080FZK	Screw (3 x 8)		6.	AAB-341		Knob (BALANCE)
2.	ANM-377	Front panel assembly		7.	ABA-193		Screw
3.	AAD-685	Knob A		8.	ANE-438		Bonnet
4.	AAD-686	Knob B		9.	AKM-041		Connection pin
5.	AAB-340	Knob (VOLUME)		10.	AEC-613		Bumper
				11.	VTZ40P100FMC		Screw (4 x 10)
				20.			Masking sheet
				21.			Rivet


A

3


C

## **Parts List**

Mark	No.	Part No.	Description	Mark	No.	Part No.	Description	Mark
⚠ ★★	1.	AEK-309	Fuse (6.3A)		11.	ASX-143	Push switch (MC/MM)	
⚠	2.	ACG-502	Ceramic (0.01/AC125V)	⚠	12.	AKP-039	AC socket	
⚠ ★★	3.	ASG-541	Push switch (POWER)		13.	ABA-234	Screw	
	4.	AAD-684	Knob (POWER)		14.	GWE-212	Tuner assembly	
	5.	ABN-048	Nut	⚠	15.	ADG-073	AC power cord	
★★	6.	AEL-169	Lamp (8V-100mA)		16.	AXC-019	Battery case	
★★	7.	AEL-171	Lamp (8V-100mA)		17.	ABA-176	Screw	
⚠ ★	8.	ATS-016	Power transformer		18.	AKB-076	Terminal (AM STEREO)	
	9.	GWK-235	Power amp assembly		19.	PMZ30P060FZB	Screw (3 x 6)	
	10.	GWX-905	Control assembly		20.	MTZ30P100FZK	Screw (3 x 10).	
					21.	BMZ40P080FZB	Screw (4 x 8)	
					22.	BBZ30P080FZK	Screw (3 x 8)	
					23.	VBZ30P060FMC	Screw (3 x 6)	
					24.	BBZ30P200FMC	Screw (3 x 20)	



A



B

C


Description	Mark	No.	Part No.	Description	Mark	No.	Part No.	Description	Mark	No.	Part No.
Push switch (MC/MM)		51.		Fuse assembly		61.		Rear panel			
AC socket		52.		Grounding terminal		62.		Switch assembly			
Screw		53.		Side frame L		63.		Connection terminal assembly			
Tuner assembly		54.		Transformer frame		64.		Heat sink holder			
AC power cord		55.		Front frame		65.		Heat sink assembly			
Battery case		56.		Rivet		66.		PCB holder			
Screw		57.		Lamp holder		67.		Side frame R			
Terminal (AM STEREO)		58.		Remote wire		68.		VCR terminal assembly			
Screw (3 x 6)		59.		Speaker switch assembly		69.		Dry battery			
Screw (3 x 10).		60.		Volume assembly		70.		Terminal (ground)			
Screw (4 x 8)						71.		Headphone jack assembly			
Screw (3 x 8)						72.		Rivet			
Screw (3 x 6)						73.		Mounting plate			
Screw (3 x 20)											

D

## Parts List

Mark	No.	Part No.	Description
▲ ★★	1.	ABA-258	Screw Q1, Q2
	2.	2SC2922/A-Y*	(2SC2922/A-P*) (2SC2922/A-G*)
▲ ★★	3.	2SA1216/A-Y*	Q3, Q4 (2SA1216/A-P*) (2SA1216/A-G*)
			*The hfe value of Q1, Q3 and Q2, Q4 must be the same.
	4.	AEC-886	Insulating sheet
	11.		Heat sink

## 5. SCHEMATIC DIAGRAM




**SWITCHES:**

S1 : CONTROL ASS'Y	S7 :
S2-1 : MODE STEREO - MONO	S8 :
S2-2 : LOUDNESS ON - OFF	S9 :
S3 : SUBSONIC ON - OFF	S10 :
S4 : SIMULATED STEREO ON - OFF	S11 :
S5-1 : TUNING MODE AUTO - MANUAL	S13 :
S5-2 : MEMORY ON - OFF	S14 :
S6 : TAPE 1 ON - OFF	S15 :

## NOTE:

The indicated semiconductors are representative ones only. Other alternative semiconductors may be used and are listed in the parts list.



SWITCHES:	CONTROL ASS'Y
S2-1 : MODE	STEREO - MONO
S2-2 : LOUDNESS	ON - OFF
S3 : SUBSONIC	ON - OFF
S4 : SIMULATED STEREO	ON - OFF
S5-1 : TUNING MODE	AUTO - MANUAL
S5-2 : MEMORY	ON - OFF
S6 : TAPE1	ON - OFF
S7 : CH1	ON - OFF
S8 : CH2	ON - OFF
S9 : CH3	ON - OFF
S10 : CH4	ON - OFF
S11 : CH5	ON - OFF
S12 : TAPE2	ON - OFF
S13 : CH6	ON - OFF
S14 : CH7	ON - OFF
S15 : CH8	ON - OFF
S16 : CH9	ON - OFF
S17 : CH10	ON - OFF
S18 : VCR	ON - OFF
S19 : AUX	ON - OFF
S20 : AM	ON - OFF
S21 : FM	ON - OFF
S22 : PHONO	ON - OFF
S23 : DOWN	ON - OFF
S24 : UP	ON - OFF

The underlined indicates the switch position.

- RESISTORS:  
Indicated in  $\Omega$ , %W, %W+5% tolerance unless otherwise noted; k, k $\Omega$ , M, M $\Omega$ , (F);  $\pm 1\%$ , (G);  $\pm 2\%$ , (K);  $\pm 10\%$ , (M);  $\pm 20\%$  tolerance
- CAPACITORS:  
Indicated in capacity ( $\mu F$ )/voltage (V) unless otherwise noted; pF. Indication without voltage is 50V except electrolytic capacitor.
- VOLTAGE CURRENT:  
[ ]: Signal voltage (V) at no input signal  
DC voltage (V) at  $8.8 W + 8.8 W$ , 8 $\Omega$  output (1kHz)  
Value in [ ] is DC voltage at rated power.
- OTHERS:  
[ ]: Signal route.  
A mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.  
\* marked capacitors and resistors have parts numbers.

This is the basic schematic diagram, but the actual circuit may vary due to improvements in design.

A

B

C

D

1 2 3 4 5 6

A

A

B


B

C

C

D

D



1 2 3 4 5 6

**SX-60**

**1**

**2**

**3**

**4**


**5**

**6**


## 6. P.C.BOARD CONNECTION DIAGRAM

TUNER Ass'y(GWR-212)

**A**




**B**




**C**

**SWITCH  
Ass'y**



Q10 Q11 Q30



**D**

**17**


**2**

**3**

**4**

**5**

**6**



VIDEO  
TERMINAL  
Ass'y

**A**

**B**

**C**

**D**

**E**

**3**

**4**

**5**

**6**

1

2

3


4

5

6


A

## CONNECTION TERMINAL Ass'y




B

## VOLUME Ass'y



C



D

B

C

1

2

3

4

5

6

7





8

9

10

11

12



7

8

9


10

11

12

22

## External Appearances of Transistors and ICs



## 7. ELECTRICAL PARTS LIST

## NOTES:

- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex. 1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J=5%, and K=10%).

560Ω 56 × 10<sup>1</sup> 561 . . . RD%PS 561 J

47kΩ 47 × 10<sup>3</sup> 473 . . . RD%PS 473 J

0.5Ω 0R5 . . . RN2H 0R5 K

1Ω 010 . . . RS1P 010 K

Ex. 2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62kΩ 562 × 10<sup>1</sup> 5621 . . . RN%SR 5621 F

- The **J** mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

- For your Parts Stock Control, the fast moving items are indicated with the marks **★★** and **\***.

**★★ GENERALLY MOVES FASTER THAN \***

This classification shall be adjusted by each distributor because it depends on model number, temperature, humidity, etc.

## Miscellaneous Parts List

## P. C. BOARD ASSEMBLIES

Mark	Part No.	Symbol & Description	Mark	Part No.	Symbol & Description
	GWE-212	Tuner assembly	★	1S1555	D1 – D4, D15, D16, D19, D30 – D33
	GWK-235	Power amp assembly	★	1S2473	
	GWX-905	Control assembly	★	1S1555	D5 – D8
	non supply	Headphone jack assembly	★	1S2471	D13, D14, D17, D18, D25, D26
	non supply	Connection terminal assembly			
	non supply	Speaker switch assembly	▲	SR3AM-4/H	D21 – D24
	non supply	Fuse assembly	★	STV2H	D28, D29
	non supply	Video terminal assembly	★	MZ-047	D9 – D12
	non supply	Switch assembly	★	MZ-290	D20
	non supply	Volume assembly	★	KZL056	D27

## OTHERS

Mark	Part No.	Symbol & Description
▲	★ ATS-016	T1 Power transformer
▲ ★	AEK-309	FU1 Fuse (6.3A)
▲	ADG-073	AC power cord
▲	AKP-039	AC socket
▲	ACG-502	C1 Ceramic (0.01/AC125V)
▲ ★	2SA985-Q*	Q3, Q4
(2SA985-R*)		
▲ ★	2SC2275-Q*	Q1, Q2
(2SC2275-R*)		
▲ ★	2SA1216/A-Y*	* The hfe value of Q1, Q3 and Q2, Q4 must be the same.
(2SA1216/A-P*)		
(2SA1216/A-G*)		
▲ ★	2SC2922/A-Y*	Q1, Q2
(2SC2922/A-P*)		
(2SC2922/A-G*)		
AKB-076	Terminal (AM STEREO)	★ 2SA1115 Q11 – Q14
★★ AEL-169	PL1 Lamp (8V-100mA)	★ 2SC2603 Q9, Q10, Q15, Q16
★★ AEL-171	PL2 Lamp (8V-100mA)	★ 2SC2240 Q21, Q22
★★ ASG-541	S1 Push switch (POWER)	★ 2SC2705/A- Q7, Q8
★★ ASX-143	Push switch (MC/MM)	★ 2SC2291 Q3, Q4
AKM-041	Connection plug	★ 2SD836A Q26




Mark	Part No.	Symbol & Description	Mark	Part No.	Symbol & Description
CQMA 332K 50	C47, C48, C87		RD1/4PMF □□□J	R17, R18, R135 – R138, R186 –	
CQMA 562K 50	C113, C114		RD1/8PM □□□J	R192, R199, R201 – R204	
CQMA 103K 50	C99, C100			Other resistors	
CEANL R47M 50	C59				
CEA R22M 50L	C3, C39, C88				
CEA 010M 50L	C40, C52, C54				
CEA 1R5M 50L	C81				
CEA 2R2M 50L	C80, C91				
CEA 4R7M 50L	C35, C41 – C44, C79, C115, C116 C127, C128, C131, C132, C139, C149, C150		★ ASS-018	X1	Crystal resonator
CEA 100M 50L	C53, C58, C74, C90, C97, C146		★ ★ ASX-175	S2	Remote slide switch (MC/MM)
CEA 220M 50L	C51, C57, C151				
CEA 101M 25L	C32, C56, C69, C119, C120, C114		PBZ30P060FMC		Screw (3 x 6)
CEA 101M 35L	C143				
CEA 221M 25L	C118				
CEA 331M 10L	C45				
CEA 471M 6L	C140				
CEA 102M 16L	C142				
CEA 332M 16L	C141				
CEA 472M 6L	C103, C104				
CEA 221M 25L	C117				

**RESISTORS**

*NOTE: When ordering resistors, convert the resistance value into code form, and then rewrite the part no. as before.*

Mark	Part No.	Symbol & Description
★ RHB8AVS103	VR2 (10k, VCO)	
★ RHB8AVS503	VR1, VR3 (50k, Separation, auto stop)	
RN1/4PQ □□□□F	R38, R70, R115, R116, R123 – R126	

**8. PACKING****Parts List**

Mark	No.	Part No.	Description
1.	AHA-346	Front pad	
2.	ARB-569	Operating instructions (English)	
3.	AHA-347	Rear pad	
4.	AHE-191	Packing case	
5.	ADH-005	FM antenna	
6.	ATB-086	Loop antenna	

## 9. ADJUSTMENT

### FM Tuner Section

Connect the FM SG to FM  $300\Omega$  antenna terminal through a  $300\Omega$  dummy antenna.

- Set FUNCTION to FM, and TUNING MODE to Manual.

Step	SG (400Hz, $\pm 75$ kHz dev.)		SX-60 frequency display	Adjustment point	Adjustment procedure
	Frequency	Level			
1	No signal		108.00MHz	L4	DC25V between TP2 and TP1 (ground)
2			87.50MHz	—	Confirm that DC voltage between TP2 and TP1 is $7V \pm 1V$ .
3	90MHz	60dB	90.00MHz	L1 – L3	Adjust so that DC voltage between TP22 and TP1 (ground) is maximum.
4	106MHz	60dB	106.00MHz	TC1 – TC3	
5	Repeat steps 3 and 4 until maximum voltage is attained.				
6	98.000MHz*	66dB	98.00MHz	T1	Adjust until DC voltage between TP22 and TP1 (ground) is maximum.
7				T2(CENTER)	DC 0V between TP3 and TP4
8				T2(DIST)	Minimize the distortion at REC 1 terminal
9	Repeat steps 7 and 8 until requirements are satisfied.				
10	98MHz	37dB	98.00MHz	VR1	Adjust so that tuning indicators are illuminated.

\* Frequency must be accurate.

### FM MPX Section

- Connect the FM multiplex stereo signal generator to the FM SG external modulation terminal.
- Set the output of the FM SG to 98.000MHz (with modulation mode set to external) and tune SX-60 to the frequency (98.00MHz)

Step	FM MPX SG		Adjustment point	Adjustment procedure
	MODULATION	LEVEL		
1	No modulation	66dB	VR2	Adjust signal at TP9 to 76kHz
2	Main (1kHz, L or R, $\pm 33.75$ kHz dev.) Pilot (19kHz, $\pm 7.5$ kHz dev.)	86dB	T1 within $\pm 90^\circ$	Minimize the distortion at REC 1 terminal
3	Main (1kHz, L or R, $\pm 33.75$ kHz dev.) Pilot (19kHz, $\pm 7.5$ kHz dev.)		VR3	Adjust until crosstalk between L and R channel (at REC 1 terminal) is minimum.

### AM Tuner Section

- Connect the AM loop antenna to AM antenna terminal.
- Set FUNCTION to AM, TUNING MODE to MANUAL position, CHANNEL STEP to 9kHz position.

Step	AM SG (400Hz, 30% MOD.)		SX-60 frequency display	Adjustment point	Adjustment procedure
	Frequency	Level			
1	No signal		522kHz	L8	DC 2V between TP2 and TP1 (ground)
2			1620kHz	TC5	DC 25V between TP2 and TP1 (ground)
3	Repeat steps 1 and 2 until the required voltage is attained.				
4	603kHz	60dB	603kHz	T3	Adjust until voltage between TP22 and TP1 (ground) is maximum.
5	1395kHz	60dB	1395kHz	TC4	
6	Repeat steps 4 and 5 until maximum voltage is attained.				

### AMPLIFIER SECTION

1. Turn VOLUME to minimum.
2. Set the SPEAKER A switch to ON.
3. Adjust VR1 so that DC voltage between TP-L and SPEAKERS A L+terminal is 40mV.
4. Adjust VR2 so that DC voltage between TP-R and SPEAKERS A R+terminal is 40mV.




Fig. 9 Adjustment Point

## 9. RÉGLAGE

### Partie tuner FM

- Brancher le générateur de signal FM sur la borne 300 ohms de l'antenne FM en intercalant une antenne fictive de 300 ohms.
- Placer le commutateur FUNCTION sur la position FM, et le mode de syntonisation (TUNING MODE) sur manuel (Manual).

Phase	SG (400Hz, $\pm 75\text{kHz}$ de déviation)		Affichage fréquence SX-60	Point de réglage	Méthode de réglage
	Fréquence	Niveau			
1	Pas de signal		108,00MHz	L4	CC25V entre TP2 et TP1 (terre)
2			87,50MHz	—	S'assurer que la tension CC entre TP2 et TP1 est de $7V \pm 1V$ .
3	90MHz	60dB	90,00MHz	L1 – L3	Continuer à régler jusqu'à ce que la tension entre TP22 et TP1 (terre) soit maximale.
4	106MHz	60dB	106,00MHz	TC1 – TC3	
5	Recommencer 3 et 4 jusqu'à ce que la tension maximale soit atteinte.				
6	98,000MHz*	66dB	98,00MHz	T1	Continuer à régler jusqu'à ce que la tension CC entre TP22 et TP1 (terre) soit maximale.
7				T2 (CENTRE)	0V CC entre TP3 et TP4.
8				T2 (DIST)	Réduire la distortion au minimum au niveau de la borne REC 1.
9	Recommencer 7 et 8 jusqu'à ce que les spécifications soient atteintes.				
10	98MHz	37dB	98,00MHz	VR1	Procéder au réglage afin que les témoins de syntonisation s'allument.

\* La fréquence doit être précise

### Section FM MULTIPLEX

- Brancher le générateur de signal multiplex FM stéréo sur la borne de modulation externe du modulateur de signal FM.
- Régler la sortie du générateur de signal FM sur 98,000MHz (le mode de modulation étant sur externe), et régler le SX-60 sur la fréquence 98,000MHz.

Phase	FM MPX SG		Point de réglage	Méthode de réglage
	Modulation	Niveau		
1	Pas de modulation	66dB	VR2	Régler le signal au niveau de TP9 sur 76kHz.
2	Principal (1kHz, D+G, déviation de $\pm 33,75\text{kHz}$ ) Pilote (19kHz, déviation de $\pm 7,5\text{kHz}$ )	86dB	T1 (entre $\pm 90^\circ$ )	Réduire la distortion au minimum au niveau de la borne REC 1.
3	Principal (1kHz, G ou D, déviation de $\pm 33,75\text{kHz}$ ) Pilote (19kHz, déviation de $\pm 7,5\text{kHz}$ )		VR3	Continuer à régler jusqu'à ce que les interférences (au niveau de la borne REC 1) entre les canaux droit et gauche soient maximales.

**PARTIE TUNER AM**

- Brancher l'antenne-cadre AM sur la borne d'antenne AM.
- Placer le commutateur FUNCTION sur AM, le mode de syntonisation sur manuel (MANUAL), et le sélecteur de canal (CHANNEL STEP) sur la position 9kHz.

Phase	AM SG (400Hz, modulation de 30%)		Affichage fréquence SX-60	Point de réglage	Méthode de réglage
	Fréquence	Niveau			
1	Pas de signal		522kHz	L8	CC 2V entre TP2 et TP1 (terre)
2			1620kHz	TC5	CC 25V entre TP2 et TP1 (terre)
3	Recommencer 1 et 2 jusqu'à ce que la tension voulue soit atteinte.				
4	603kHz	60dB	603kHz	T3	Continuer à régler jusqu'à ce que la tension entre TP22 et TP1 (terre) soit maximale.
5	1395kHz	60dB	1395kHz	TC4	
6	Recommencer 4 et 5 jusqu'à ce que la tension maximale soit atteinte.				

**PARTIE AMPLIFICATRICE**

1. Régler le volume (VOLUME) au minimum.
2. Placer le commutateur du haut-parleur A sur marche (ON).
3. Régler VR1 afin que la tension CC entre TP-L et la borne + gauche (L) du haut-parleur A soit de 40mV.
4. Régler VR2 afin que la tension entre TP-R et la borne + droit (R) du haut-parleur A soit de 40mV.




Fig. 9 Point de réglage

## 9. AJUSTE

### Sección del sintonizador de FM

- Conectar un generador de señales de FM (FM SG) al terminal de antena de FM de 300 ohmios mediante una antena ficticia.
- Poner el selector de función (FUNCTION) en la posición FM y el del modo de sintonización (TUNING MODE) en la de Manual.

Paso	SG (400Hz, ±75kHz de desv.)		Frecuencímetro del SX-60	Punto de ajuste	Procedimiento de ajuste
	Frecuencia	Nivel			
1	Sin señal		108,00MHz	L4	25V CC entre TP2 y TP1 (masa)
2			87,50MHz	—	Confirmar que la tensión de CC entre TP2 y TP1 sea de 7V±1V.
3	90MHz	60dB	90,00MHz	L1 – L3	Ajustar de modo que la tensión de CC entre TP22 y TP1 (masa) sea la máxima.
4	106MHz	60dB	106,00MHz	TC1 – TC3	
5	Repetir los pasos 3 y 4 hasta obtenerse la tensión máxima.				
6	98,000MHz*	66dB	98,00MHz	T1	Ajustar hasta que la tensión de CC entre TP22 y TP1 (masa) sea la máxima.
7				T2 (CENTER)	0V CC entre TP3 y TP4
8				T2 (DIST)	Minimizar la distorsión en el terminal REC 1
9	Repetir los pasos 7 y 8 hasta satisfacerse los requisitos.				
10	98MHz	37dB	98,00MHz	VR1	Ajustar de modo que se iluminen los indicadores de sintonización.

\* La frecuencia debe ser precisa.

### Sección de multiplex de FM (FM MPX)

- Conectar un generador de señales estereofónicas de multiplex de FM al terminal de modulación exterior FM SG (generador de señales de FM).
- Ajustar la salida del FM SG a 98,000MHz (con el modo de modulación ajustado a externa) y sintonizar el SX-60 a la frecuencia (98,000MHz).

Paso	FM MPX SG		Punto de ajuste	Procedimientos de ajuste
	Modulación	Nivel		
1	Sin modulación	66dB	VR2	Ajustar la señal en YP9 a 76kHz.
2	Principal (1kHz, Izq. + Der., ±33,75kHz de desv.) Piloto (19kHz, ±7,5kHz de desv.)	86dB	T1 (dentro de ±90°)	Minimizar la distorsión en el terminal REC 1.
3	Principal (1kHz, Izq. y Der., ±33,75kHz de desv.) Piloto (19kHz, ±7,5kHz de desv.)		VR3	Ajustar hasta que la diafonía entre los canales Izq. y Der. (en el terminal REC 1) sea la mínima.

### Sección del sintonizador de AM

- Conectar la antena de cuadro de AM al terminal para antena de AM.
- Poner el selector de función (FUNCTION) en la posición AM, el de modo de sintonización en la posición MANUAL, y el se paso de canal (CHANNEL STEP) en la posición de 9kHz.

Paso	AM SG (400Hz, 30% de mod.)		Frecuencímetro del SX-60	Punto de ajuste	Procedimientos de ajuste
	Frecuencia	Nivel			
1	Sin señal		522kHz	L8	2V CC entre TP2 y TP1 (masa)
2			1620kHz	TC5	25V CC entre TP2 y TP1 (masa)
3	Repetir los pasos 1 y 2 hasta que se logre la tensión requerida.				
4	603kHz	60dB	603kHz	T3	Ajustar hasta que la tensión entre TP22 y TP1 (masa) sea la máxima.
5	1395kHz	50dB	1395kHz	TC4	
6	Repetir los pasos 4 y 5 hasta obtenerse la tensión máxima.				

### SECCION DEL AMPLIFICADOR

1. Girar el control VOLUME a la posición mínima.
2. Poner el selector de altavoces A (SPEAKER A) en ON.
3. Ajustar VR1 de modo que la tensión de CC entre los terminales TP-L y L + SPEAKER A sea de 40mV.
4. Ajustar VR2 de modo que la tensión de CC entre los terminales TP-R y R + SPEAKER A sea de 40mV.




Fig. 9 Punto de ajuste


## 10. SAFETY INFORMATION

### 1. SAFETY PRECAUTIONS

The following check should be performed for the continued protection of the customer and service technician.

#### LEAKAGE CURRENT CHECK

Measure leakage current to a known earth ground (water pipe, conduit, etc.) by connecting a leakage current tester such as Simpson Model 229-2 or equivalent between the earth ground and all exposed metal parts of the appliance (input/output terminals, screwheads, metal overlays, control shaft, etc.). Plug the AC line cord of the appliance directly into a 120V AC 60Hz outlet and turn the AC power switch on. Any current measured must not exceed 0.5mA.



ANY MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE APPLIANCE TO THE CUSTOMER.

### 2. PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in the appliance have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a  $\Delta$  on the schematics and on the parts list in this Service Manual.

The use of a substitute replacement component which does not have the same safety characteristics as the PIONEER recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire, or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current PIONEER Service Manual. A subscription to, or additional copies of, PIONEER Service Manual may be obtained at a nominal charge from PIONEER.